



# INSTALLATION AND OPERATING INSTRUCTIONS

Robot-specific SCM and Comfort App  
for Denso robots

DDOC01259

THE KNOW-HOW FACTORY

## Glossary

Parameter	Explanation
Cmd_Grip	Motion command for gripping the workpiece
Cmd_Release	Motion command for releasing the workpiece
IsReleased	The gripper signals that it is open.
IsGrasped	The gripper has gripped the workpiece and the position is within the taught-in workpiece window.
IsClosed	The gripper has gripped but there is no workpiece, so it is in the maximum position.

## Content

1	Supporting documents .....	5
1.1	Notices and graphics in the installation and operating instructions .....	5
2	Safety notices .....	6
3	Proper use .....	6
4	Personnel qualification .....	7
4.1	Electricians .....	7
4.2	Specialists .....	7
4.3	Instructed personnel.....	7
4.4	Service personnel.....	7
4.5	Additional qualifications .....	7
5	Product description .....	8
6	Functional description .....	9
6.1	LED status display .....	9
6.1.1	Basic module LED display .....	9
6.1.2	IO module LED display.....	9
7	Technical data .....	10
8	Accessories/scope of delivery .....	10
9	Transportation/storage/preservation .....	10
10	Installation .....	11
10.1	Installing hardware.....	11
10.1.1	Installing standard wiring .....	12
10.1.2	Wiring of the robot IO card .....	13
10.1.3	Standard wiring for individual grippers.....	14
10.1.4	Standard wiring for two grippers.....	18
10.1.5	Advanced configuration .....	18
10.2	Installing the energy supply .....	19
10.2.1	Mounting the pin assignment.....	19
10.2.2	Installing the power supply for the basic module .....	20
10.2.3	Installing the power supply for the IO module.....	20
10.2.4	Installing IO-Link .....	21
11	Installation HMI .....	21
12	Commissioning HMI .....	21
13	Installation Comfort App .....	22
14	Commissioning Comfort App .....	23
14.1	Deleting existing setups .....	23
14.2	Creating a gripper configuration .....	24
14.2.1	Selecting the connection type.....	24
14.2.2	Gripper connection type .....	24
14.2.3	MATCH connection type .....	30
15	Operation .....	34
15.1	Control principle of the gripper .....	34
15.2	Overview of generated robot jobs .....	34
16	Error diagnosis .....	36

17 RoHS declaration.....37

18 Declaration of Conformity .....38

19 Declaration of Conformity .....39

## 1 Supporting documents

### NOTICE



Read through the installation and operating instructions before installing or working with the product.

The installation and operating instructions contain important notes for your personal safety. They must be read and understood by all persons who work with or handle the product during any phase of the product lifetime.



The documents listed below are available for download on our website [www.zimmer-group.com](http://www.zimmer-group.com).

- Installation and operating instructions
  - Catalogs, drawings, CAD data, performance data
  - Information on accessories
  - Technical data sheets
  - General Terms and Conditions, including warranty information.
- ⇒ Only those documents currently available on the website are valid.

In these installation and operating instructions, "product" refers to the product designation on the title page!

### 1.1 Notices and graphics in the installation and operating instructions

#### DANGER



This notice warns of an imminent danger to the life and health of people. Ignoring these notices can lead to serious injury or even death.

► You absolutely must comply with the described measures for avoiding these dangers!

⇒ The warning symbols are assigned according to the type of danger.

#### WARNING



This notice warns of a situation that is potentially hazardous to personal health. Ignoring these notices can cause serious injury or damage to health.

► You absolutely must comply with the described measures for avoiding these dangers!

⇒ The warning symbols are assigned according to the type of danger.

#### CAUTION



This notice warns of a situation that is potentially hazardous to persons. Ignoring these notices can cause minor, reversible injuries.

► You absolutely must comply with the described measures for avoiding these dangers!

⇒ The warning symbols are assigned according to the type of danger.

#### NOTICE



This notice warns of possible material and environmental damage. Ignoring these notices can result in damage to the product or the environment.

► You absolutely must comply with the described measures for avoiding these dangers!

⇒ The warning symbols are assigned according to the type of danger.

#### INFORMATION



This category contains useful tips for handling the product efficiently. Failure to observe these tips will not result in damage to the product. This information does not include any information relevant to health or workplace safety.

## 2 Safety notices

### CAUTION



#### **Risk of injury and material damage in case of non-compliance**

Installation, commissioning, maintenance and repairs may only be performed by qualified specialists in accordance with these installation and operating instructions.

The product is state-of-the-art.

Grippers with a control system are used on industrial machines for IO-Link communication.

The following are examples of situations in which the product may cause a hazard:

- The product is not properly installed, used or maintained.
- The product is not used for its designated purpose.
- The locally applicable regulations, laws, directives or guidelines are not observed.
- ▶ The product may only be used in accordance with these installation and operating instructions and the product's technical data.
- ⇒ Zimmer GmbH shall accept no liability for any damage caused by improper use. The operator bears sole responsibility.

## 3 Proper use

### NOTICE



#### **Material damage and malfunction in case of non-compliance**

The product is only to be used in its original state with its original accessories, with no unauthorized changes and within the stipulated parameter limits and operating conditions.

Any other or secondary use is deemed improper.

- ▶ Operate the product only in compliance with the associated installation and operating instructions.
- ▶ Operate the product only when it is in a technical condition that corresponds to the guaranteed parameters and operating conditions.
- ⇒ Zimmer GmbH shall accept no liability for any damage caused by improper use. The operator bears sole responsibility.

- The product is designed exclusively for electric operation using a 24 V DC power supply.
- Direct contact with perishable goods/food is not permitted.

## 4 Personnel qualification

### WARNING



#### **Inadequate qualification can cause injury and material damage**

If inadequately qualified personnel perform work on the product, this can cause serious injuries and significant material damage.

- ▶ All work on the product must be performed by qualified personnel.
- ▶ Before working with the product, read the document in its entirety and make sure that you have understood everything.
- ▶ Observe country-specific accident prevention regulations and the general safety notices.

The following qualifications are a prerequisite for performing various work on the product.

#### **4.1 Electricians**

Electricians are able to perform work on electrical systems, can recognize and avoid possible dangers and know the relevant standards and provisions due to their technical training, knowledge and experience.

#### **4.2 Specialists**

Specialists are able to perform the assigned work, can recognize and avoid possible dangers and know the relevant standards and provisions due to their technical training, knowledge and experience.

#### **4.3 Instructed personnel**

Instructed personnel have been trained by the operating company on the tasks and possible dangers of improper behavior.

#### **4.4 Service personnel**

Service personnel are able to perform the assigned work and can recognize and avoid possible dangers due to their technical training, knowledge and experience.

#### **4.5 Additional qualifications**

Persons who work with the product must be familiar with the valid safety regulations and laws as well as the standards, guidelines and laws listed in this document.

Personnel who work with the product must have facility-issued authorization to commission, program, configure, operate, maintain and also decommission this product.

## 5 Product description


The Smart Communication Module (SCM) is a gateway between the grippers and the robot control system. The SCM can be configured via the HMI software or Comfort App. The grippers can be controlled using the Comfort App on the robot control panel.

Using the Comfort App, Zimmer GmbH grippers can be controlled directly from the robot control panel and generated robot jobs can be configured.

The generated robot tasks simplify the use of Zimmer GmbH grippers in the customer program and reduce the development time.

The names of the newly configured robot jobs remain unchanged. This means that the basic program does not have to be modified for configuration changes.

The image shows a simplified view of the structure of the overall system. All parts for the electrical connection of a gripper with the robot are included or are available from Zimmer GmbH as optional accessories.



Installation steps:

- Install the hardware.
- Establish the electrical connections at the robot control system.
- Install the HMI software and teach in the workpieces.
- Install the Comfort App, see the operating instructions for the robot-specific Comfort App.






## 6 Functional description





### 6.1 LED status display

The LED display is provided on each submodule. The left module with the network sockets is the basic module. The right module with the digital IO is the IO module.

#### 6.1.1 Basic module LED display

Name	Status	Function
	Continuous light	Supply voltage OK
	Flashing	HMI is connected, the SCM is teaching the IO-Link device.
	Flashing	HMI assumes control, the IO module LEDs are off.
	off	Supply voltage not OK
	Continuous light	An error is present
	Flashing	There is an external error, see the "Error diagnosis" section.
Status 1/2 (IO-Link device)	off	HMI is connected.
	Continuous light	HMI is disconnected, IO-Link device has an error.
	Flashing	IO-Link device is disconnected.
	Continuous light	HMI is disconnected, IO-LINK device is open or closed at a standstill.
	Continuous light	HMI is disconnected, IO-LINK device is in motion or on the workpiece.
 (P 24 V)	Continuous light	Actuator voltage OK
	off	Actuator voltage not OK

#### 6.1.2 IO module LED display

Name	Status	Function
	Continuous light	• Supply voltage OK
	off	• HMI is disconnected, supply voltage is not OK.
		• HMI is connected, supply voltage is OK.
	Continuous light	• An error is present
	Flashing	• There is an external error, see the "Error diagnosis" section.
Status 1/2 (IO-Link device)	off	• HMI is connected, the IO module is inactive.
	Continuous light	• Gripper has a motion task in the <i>release</i> direction.
	Continuous light	• Gripper has a motion task in the <i>grasp</i> direction.
  (P 24 V)	Continuous light	• Actuator voltage OK
	off	• Actuator voltage not OK
-	Inactive	-

## 7 Technical data

### INFORMATION



- ▶ You can find the information in the technical data sheet on our website.
- This data varies within the series, depending on the specific design.

## 8 Accessories/scope of delivery

### INFORMATION



- If any accessories not sold or authorized by Zimmer GmbH are used, the function of the product cannot be guaranteed. Zimmer GmbH accessories are specifically tailored to the individual products.
- ▶ For optional accessories and those included in the scope of delivery, refer to our website.

## 9 Transportation/storage/preservation

- ▶ Transport and storage of the product must be done only with the original packaging.
- ▶ If the product has already been installed on the superordinate machine unit, care must be taken during transport to ensure that no unexpected movements can occur.
  - ▶ Before commissioning the product and after transport, check all power and communication connections as well as all mechanical connections.
- ▶ Visually inspect all components.

## 10 Installation

### WARNING



#### Risk of injury due to uncontrolled movements

Risk of injury in case of unexpected movement of the machine or system into which the product is to be installed.

- ▶ Switch off the energy supply of the machine before any work.
- ▶ Secure the power supply against being switched on unintentionally.
- ▶ Check the machine for any residual energy that may be present.

### CAUTION



#### Risk of injury due to uncontrolled movements

Risk of injury in the event of uncontrolled movement of the product when the power supply is connected.

- ▶ Switch off the power supply to the machine before carrying out any work.
- ▶ Secure the power supply against being switched on unintentionally.
- ▶ Check the machine for any residual energy that may be present.

### 10.1 Installing hardware

The product is designed for installation on a standard 35 mm-wide profile rail.


The mounting position can be upright on the profile rail or suspended (profile rail mounted in the control cabinet).

- ▶ Keep a clearance of 5 cm each on the side of the ventilation slots of the product for air circulation.

### INFORMATION



- ▶ For more information, refer to the circuit diagram on our website.



### 10.1.1 Installing standard wiring

#### NOTICE



The gripper wiring must match the gripper configuration done in the Comfort App.

#### NOTICE




Because the robot control system does not provide sufficient power, an external power supply unit is necessary for the 24 V power supply.

For the connection assignment of the robot inputs and robot outputs, refer to the manufacturer documentation.

For the connection assignment of the SCM inputs and SCM outputs, refer to the installation and operating instructions of the SCM. The installation and operating instructions of the SCM are downloaded along with the Zimmer HMI.

► Note the potential equalization by connecting the GND/0V potentials of the SCM and robot control system.



The standard wiring corresponds to the standard configuration in the Comfort App. If you do the standard wiring and keep the standard configuration in the Comfort App, your grippers will function with the robot.

You have the option to change the standard wiring.

One reason for changing the standard wiring is when the robot input and output numbers are already used for a different external application and thus you cannot assign these to the gripper functions.

Another reason is if, on your robot, you can assign more than eight robot inputs and eight robot outputs to the gripper functions. In this case, you can use the full functionality of the SCM by assigning all SCM inputs and SCM outputs to the robot inputs and robot outputs.

### 10.1.2 Wiring of the robot IO card

Mini IO or Hand IO can be used on the Denso robot control system.

The default setting for the Comfort App is Hand IO input Hin1 to 8 and Hand IO output Hout1 to 8.


#### INFORMATION



► For more information on the robot control system, refer to the manufacturer documentation.

#### 10.1.2.1 Connection assignment Hand IO input and Hand IO output [PNP type]

View of cable side




Terminal no.	Name	Connection no.	Wire color	
			Standard	Reinforced
1	Hand IO output	64	Black	Blue
2	Hand IO output	65	Brown	Yellow
3	Hand IO output	66	Black	Green
4	Hand IO output	67	Brown	Red
5	Hand IO output	68	Red	Violet
6	Hand IO output	69	Orange	Blue
7	Hand IO output	70	Yellow	Yellow
8	Hand IO output	71	Green	Green
9	Hand IO input	48	Blue	Red
10	Hand IO input	49	Violet	Violet
11	Hand IO input	50	Pink	White
12	Hand IO input	51	Pink	White
13	Hand IO input	52	White	White
14	Hand IO input	53	White	White
15	Hand IO input	54	White	White
16	Hand IO input	55	White	Brown
17	Current output (0 V DC) (external/internal source)	-	White	Brown
18	Current output (24 V DC) (external/internal source)	-	White	Brown
19	-	-	White	Brown
20	-	-	White	Brown

### 10.1.3 Standard wiring for individual grippers

SCM input and SCM output		
	Basic gripper	Advanced gripper
Cmd_Release	Out1	Out1
Cmd_Grip	Out2	Out2
Cmd_Reset	Out3	Out3
Cmd_MotorOn	-	Out4
Cmd_Homing	-	Out5
Cmd_WP_Bit0	Out6	Out6
Cmd_WP_Bit1	Out7	Out7
Cmd_WP_Bit2	-	-
Cmd_WP_Bit3	-	-
IsReleased	In1	In1
IsGripped	In2	In2
IsClosed	In3	In3
OnUndefinedPos	In4	In4
Error	In5	In5
MotorOn	-	In6
HomingOk	-	-
Act_WP_Bit0	In7	In7
Act_WP_Bit1	In8	In8
Act_WP_Bit2	-	-
Act_WP_Bit3	-	-

The following image shows the standard wiring for the Advanced gripper:



### 10.1.3.1 Basic gripper

If you keep the standard wiring, you can address workpiece numbers 1 to 7 because the SCM input Cmd\_WP\_Bit3 and the SCM output Act\_WP\_Bit3 are not connected.

Deviate from the standard wiring and add the necessary signals in the wiring to address all workpiece numbers from 1 to 15. A corresponding assignment of the SCM inputs and SCM outputs in the Comfort App is required.

SCM connection	Command	Color	Robot output
1	Cmd_Release	White	Hout1
2	Cmd_Grip	Brown	Hout2
3	Cmd_Reset	Green	Hout3
4	-	-	-
5	-	-	-
6	-	-	-
7	-	-	-
8	-	-	-
9	Cmd_WP_Bit0	Black	Hout6
10	Cmd_WP_Bit1	Violet	Hout7
11	Cmd_WP_Bit2	Gray/pink	(Hout8)
12	Cmd_WP_Bit3	Red/blue	-
SCM connection	Confirmation	Color	Robot input
1	IsReleased	White	Hin1
2	IsGripped	Brown	Hin2
3	IsClosed	Green	Hin3
4	OnUndefinedPos	Yellow	Hin4
5	Error	Gray	Hin5
6	-	-	-
7	-	-	-
8	-	-	-
9	Act_WP_Bit0	Black	Hin6
10	Act_WP_Bit1	Violet	Hin7
11	Act_WP_Bit2	Gray/pink	-
12	Act_WP_Bit3	Red/blue	-



### 10.1.3.2 Advanced gripper

If you keep the standard wiring, you can address workpiece numbers 1 to 3, because the SCM inputs (Cmd\_WP\_Bit2 and Cmd\_WP\_Bit3) and SCM outputs (Act\_WP\_Bit2 and Act\_WP\_Bit3) are not connected.

Deviate from the standard wiring and add the necessary signals in the wiring to address all workpiece numbers from 1 to 15. A corresponding assignment of the SCM inputs and SCM outputs in the Comfort App is required.

SCM connection	Command	Color	Robot output
1	Cmd_Release	White	Hout1
2	Cmd_Grip	Brown	Hout2
3	Cmd_Reset	Green	Hout3
4	Cmd_MotorOn	Yellow	Hout4
5	Cmd_Homing	Gray	Hout5
6	-	-	-
7	-	-	-
8	-	-	-
9	Cmd_WP_Bit0	Black	Hout6
10	Cmd_WP_Bit1	Violet	Hout7
11	Cmd_WP_Bit2	Gray/pink	(Hout8)
12	Cmd_WP_Bit3	Red/blue	-
SCM connection	Confirmation	Color	Robot input
1	IsReleased	White	Hin1
2	IsGripped	Brown	Hin2
3	IsClosed	Green	Hin3
4	OnUndefined	Yellow	Hin4
5	Error	Gray	Hin5
6	MotorOn	Pink	Hin6
7	HomingOk	Blue	-
8	-	-	-
9	Act_WP_Bit0	Black	Hin7
10	Act_WP_Bit1	Violet	Hin8
11	Act_WP_Bit2	Gray/pink	-
12	Act_WP_Bit3	Red/blue	-

#### 10.1.4 Standard wiring for two grippers

In the scenario with two grippers, the SCM does not add the SCM inputs and SCM outputs provided for the workpiece numbers. Even if your robot has additional robot input and robot output lines available, only one workpiece per gripper is addressed. Some of the status lines, such as *isUndefinedPosition*, *isHomingOK*, *isMotorOn* are not used in some of the standard configurations.

SCM input and SCM output				
	Basic gripper at port 1	Advanced gripper at port 1	Basic gripper at port 2	Advanced gripper at port 2
Cmd_Release	Out1	Out1	Out5	Out5
Cmd_Grip	Out2	Out2	Out6	Out6
Cmd_Reset	Out3	-	Out7	-
Cmd_MotorOn	-	Out3	-	Out3 or Out7
Cmd_Homing	-	Out4	-	Out8
Cmd_WP_Bit0	-	-	-	-
Cmd_WP_Bit1	-	-	-	-
Cmd_WP_Bit2	-	-	-	-
Cmd_WP_Bit3	-	-	-	-
IsReleased	In1	In1	In5	In5
IsGripped	In2	In2	In6	In6
IsClosed	In3	In3	In7	In7
OnUndefinedPos	-	-	-	-
Error	In4	In4	In8	In8
MotorOn	-	-	-	-
HomingOk	-	-	-	-
Act_WP_Bit0	-	-	-	-
Act_WP_Bit1	-	-	-	-
Act_WP_Bit2	-	-	-	-
Act_WP_Bit3	-	-	-	-


#### 10.1.5 Advanced configuration

You can use the full functionality of the SCM by using more robot inputs and robot outputs. The functional assignment of the robot input and robot output numbers can be modified. A corresponding configuration of the extended wiring in the Comfort App is required.

## 10.2 Installing the energy supply

### 10.2.1 Mounting the pin assignment

- ① Status
- ② Ethernet port
- ③ IO-Link X1
- ④ IO-Link X2
- ⑤ Power supply of basic module X3
- ⑥ Digital input X4
- ⑦ Digital input X5
- ⑧ Digital output X6
- ⑨ Digital output X7
- ⑩ Power supply of IO module X8



### 10.2.2 Installing the power supply for the basic module

- Fuse the product using a suitable circuit breaker in accordance with the expected current draw and the cable cross-sections used.

#### INFORMATION



The signal and actuator voltage is electrically isolated in the product.

- Connect a maximum load of 10 A to pin 1 and pin 2.
- Connect a maximum load of 500 mA to pin 3 and pin 4.


The maximum permitted current draw allows you to operate all grippers directly on the product. No Y-plug-in connector for a special power supply is required.

Pin	Function	Explanation	Power supply of basic module X3
1	24 V DC actuator	Actuator supply voltage	
2	GND actuator	0 V DC actuator supply voltage	
3	24 V DC input signal	SCM supply voltage and signal voltage for the grippers	
4	GND input signal	SCM ground and signal voltage for the grippers	
5	24 V DC output signal	Signal voltage output for supplying power to the I/O module (connect to pin 17)	
6	GND output signal	GND output for supplying power to the I/O module (connect to pin 18)	

### 10.2.3 Installing the power supply for the IO module

Pin	Function	Explanation	Power supply of IO module X8
13	-	-	
14	-	-	
15	-	-	
16	-	-	
17	24 V DC	24 V DC supply voltage	
18	GND	0 V DC supply voltage	

- Connect pin 5 of the basic module to pin 17 of the IO module.
- Connect pin 6 of the basic module to pin 18 of the IO module.



## 10.2.4 Installing IO-Link

### NOTICE



**Non-compliance may result in material damage.**

If the wiring is done differently, the gripper will be damaged.

If the gripper has an additional STO cable (Safe-Torque-OFF), this is wired with the external safety circuit independently of the SCM.

The pin assignments listed in the table are for both IO-Link channels.

IO-Link X1/IO-Link X2				IO-Link X1/IO-Link X2	M12 5-pin socket	
Pin	Color	Function	Explanation		Pin	Color
1	Black	C/Q	IO-Link communication		4	Black
2	-	-	-	<b>M12 5-pin socket</b> 	6	-
3	White	PWR actuator	Actuator supply voltage		2	White
4	Gray	GND actuator	0 V DC actuator supply voltage		5	Gray
5	Brown	24 V DC sensor	Supply voltage of sensor		1	Brown
6	Blue	GND sensor	0 V DC sensor supply voltage		3	Blue

## 11 Installation HMI

### INFORMATION



► For information, refer to the commissioning instructions for the HMI.

## 12 Commissioning HMI

### INFORMATION



► For information, refer to the commissioning instructions for the HMI.

## 13 Installation Comfort App

- Download the Comfort App from our website.


### INFORMATION



The Comfort App consists of two main parts:

- *ZimmerComfortApp.pns*: main screen for entering mapping mode. All control panels, headers and program files for visual address assignment can be used and the gripper settings can be stored for use.
- *GripperSettings.pcs*: gripper settings for use.

- Open your WINCAPSIII robot application project.
- In the menu bar, click *Project*.
  - Click *Add Existing File*.
- Select the desired project source file in the folder *//Setup Source Files*:
  - Header file (\*.h)
  - *ZimmerComfortApp.pns*
  - *GripperSettings.pcs*



The Comfort App uses public variables of the robot control system.

- Initialize the public variables of the robot control system.
- Execute the call *ZG\_ComfortApp\_Initialize()* in automatic mode.



## 14 Commissioning Comfort App

### NOTICE




- Switch on the robot so that you can use the Comfort App.

### 14.1 Deleting existing setups

The following screen is displayed only if an existing setup is found for two grippers.


This screen does not appear if the available setup is only found for one gripper. In this case, the next screen is shown right away.

- Click the button of the desired gripper.
- ⇒ The *Manual control* screen for the manual control is displayed.




In the *Manual control* screen, you can operate the gripper manually and display the status.

- Click the *delete* button.




- In the prompt, click the *YES* button.
- ⇒ The existing setup is deleted.
- ⇒ The screen sequence for configuring new grippers is displayed.



## 14.2 Creating a gripper configuration

### 14.2.1 Selecting the connection type


- Click *Gripper* if you have connected a gripper.
- Click *MATCH* if you have connected a MATCH gripper.
- Click the *next* button.



### 14.2.2 Gripper connection type

#### 14.2.2.1 Selecting the number of grippers


- Click the desired number of grippers you want to have in your robot application.
- Click the *next* button.





### 14.2.2.2 Selecting the gripper type

- Click the desired gripper type.
- Click the *next* button.




### 14.2.2.3 Selecting the gripper series

#### INFORMATION



*Basic* and *Advanced* designate different classes of grippers from Zimmer GmbH.

- Click the class of your gripper.
- Click the *next* button.



#### 14.2.2.4 Manual control

##### NOTICE




The prerequisite for the function test is that the wiring between the robot and SCM is present and that the robot, SCM and gripper are switched on.

You can test and operate the function of the gripper and view its status in the lower area of the screen.

► Click the *Customizing IOs* button.

⇒ The *Select command connections* screen for selecting the command connections is displayed.



### 14.2.2.5 Selecting the command connections

#### NOTICE



The gripper wiring must match the gripper configuration done in the Comfort App.

#### NOTICE



If this screen is displayed for the first time, a standard assignment is displayed.

► Complete the wiring precisely as shown on this screen.

To reset the values to the defaults, edit the values or return to the selection of the number of grippers (see the section "Selecting the number of grippers").

► Establish the correspondence of the robot output number with the digital input function of the SCM.

You can accept the default assignment or change it.

► Click the *next* button if you want to keep the default assignment.

#### Editing the command connection

► Click the button of the desired signal.

- e.g. Release

► Click the desired output.


- e.g. HOUT7

⇒ The output has been assigned to the signal.

⇒ The button of the signal is expanded by adding the output.

- e.g. Release (HOUT7)

► Click the *next* button.



► In the prompt, click the *YES* button.

⇒ The *Select status connections* screen for status connections is displayed.

#### Default assignment



Do you accept default assignment?

Ja

Nein

### 14.2.2.6 Selecting the status connections

- Establish the correspondence of the robot input number with the digital input function of the SCM.

#### NOTICE



If this screen is displayed for the first time, a standard assignment is displayed.


- Complete the wiring precisely as shown on this screen.

You can accept the default assignment or change it.

- Click the *next* button if you want to keep the default assignment.

#### Editing the command connection

- Click the button of the desired signal.
  - e.g. Release
- Click the desired output.
  - e.g. HOUT7
- ⇒ The output has been assigned to the signal.
- ⇒ The button of the signal is expanded by adding the output.
  - e.g. Release (HOUT7)
- Click the *next* button.



- In the prompt, click the YES button.

#### Default assignment




Do you accept default assignment?

Ja

Nein

### 14.2.2.7 Storing gripper configuration

- ⇒ The *Manual control* screen for the manual control is displayed.
- For more information, refer to the section "Manual control".
- Click the *next* button.
- ⇒ The gripper configuration is complete.
- ⇒ The function blocks/subprograms have been created and are available for programming.



### 14.2.3 MATCH connection type

#### 14.2.3.1 Manual control

##### NOTICE




The prerequisite for the function test is that the wiring between the robot and SCM is present and that the robot, SCM and gripper are switched on.

You can test and operate the function of the gripper and view its status in the lower area of the screen.

You can use the option fields to choose between the grippers.

► Click the *Customizing IOs* button.

⇒ The *Select command connections* screen for selecting the command connections is displayed.



### 14.2.3.2 Selecting the command connections

#### NOTICE



If this screen is displayed for the first time, a standard assignment is displayed.

► Complete the wiring precisely as shown on this screen.

To reset the values to the defaults, edit the values or return to the selection of the number of grippers (see the section "Selecting the number of grippers").

► Establish the correspondence of the robot output number with the digital input function of the SCM.

You can accept the default assignment or change it.

► Click the *next* button if you want to keep the default assignment.

#### Editing the command connection

► Click the button of the desired signal.

- e.g. Release

► Click the desired output.


- e.g. HOUT7

⇒ The output has been assigned to the signal.

⇒ The button of the signal is expanded by adding the output.

- e.g. Release (HOUT7)

► Click the *next* button.



► In the prompt, click the *YES* button.

⇒ The *Select status connections* screen for status connections is displayed.

#### Default assignment



Do you accept default assignment?

Ja

Nein



### 14.2.3.3 Selecting the status connections

- Establish the correspondence of the robot input number with the digital input function of the SCM.

#### NOTICE



If this screen is displayed for the first time, a standard assignment is displayed.


- Complete the wiring precisely as shown on this screen.

You can accept the default assignment or change it.

- Click the *next* button if you want to keep the default assignment.

#### Editing the command connection

- Click the button of the desired signal.
  - e.g. Release
- Click the desired output.
  - e.g. HOUT7
- ⇒ The output has been assigned to the signal.
- ⇒ The button of the signal is expanded by adding the output.
  - e.g. Release (HOUT7)
- Click the *next* button.



- In the prompt, click the YES button.

#### Default assignment



Do you accept default assignment?


Ja

Nein



#### 14.2.3.4 Storing gripper configuration

- ⇒ The *Manual control* screen for the manual control is displayed.
- For more information, refer to the section "Manual control".
- Click the *next* button.
- ⇒ The gripper configuration is complete.
- ⇒ The function blocks/subprograms have been created and are available for programming.



## 15 Operation

### 15.1 Control principle of the gripper

- ▶ Prepare *Advanced* grippers for the control system:
  - ▶ If necessary, do a reference run (ZHOMING).
  - ▶ Check if the reference run was done (ZISHOMINGOK or ZISHOMINGSUCCESS).
  - ▶ Switch on the motor (ZMOTORON).
  - ▶ Check whether the motor is switched on (ZISMOTORON).
- ⇒ The gripper is prepared for the control system if no error is present (ZISERROR).
- ▶ Set a workpiece configured with the HMI software ZG\_IO\_LINK\_HMI (ZCHANGEWP(number)) if more than one workpiece is used.
- ▶ Check whether a workpiece has changed (Z\_ISWPCHANGED(number)).
- ▶ Grip (ZGRIP) or release (ZRELEASE) the workpiece.
- ▶ Check the position of the gripper jaw (ZISONTTEACHPOS, ZISOPENED, ZISCLOSED or ZISONUNDEFPOS).

### 15.2 Overview of generated robot jobs

After successful configuration of the grippers using the HMI software, robot jobs for various functions are generated in the robot control panel. The robot jobs can be called up from user jobs. The following robot jobs can be created using the Comfort App.

Not all robot jobs are generated after successful configuration of the grippers. The job is created only if the corresponding command or status is wired and used by the equipped gripper(s).

Generated robot job name	Parameter In	Parameter Out	Function
ZGRIP1 ZGRIP2	1: Address gripper 1 2: Address gripper 2	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Gripping
ZRELEASE1 ZRELEASE2	1: Address gripper 1 2: Address gripper 2	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Release
ZMOTORON1 ZMOTORON2	1: Address gripper 1 2: Address gripper 2	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Switch on motor for <i>Advanced</i> grippers.
ZMOTOROFF1 ZMOTOROFF2	1: Address gripper 1 2: Address gripper 2	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Switch off motor if gripper is present.
ZHOMING1 ZHOMING2	1: Address gripper 1 2: Address gripper 2	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Perform reference run for <i>Advanced</i> grippers.
ZRESET1 ZRESET2	1: Address gripper 1 2: Address gripper 2	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Reset if gripper is present.
ZCHANGEWP1 ZCHANGEWP2	<i>WpNumber</i> = workpiece number (1 to 15)	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Set workpiece number (n) for use with SCM.
ZISWPCHANGED1 ZISWPCHANGED2	<i>WpNumber</i> = workpiece number (1 to 15)	<i>bWpchanged</i> = <i>TRUE</i> , if workpiece is active = <i>FALSE</i> , if workpiece is not active  <i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Outputs <i>TRUE</i> if workpiece number (n) is activated.

Generated robot job name	Parameter In	Parameter Out	Function
ZISOPENED1 ZISOPENED2	1: Address gripper 1 2: Address gripper 2	<i>bOpened</i> = <i>TRUE</i> , if gripper is open = <i>FALSE</i> , if gripper is closed	Outputs <i>TRUE</i> if the gripper is open.
		<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	
ZISCLOSED1 ZISCLOSED2	1: Address gripper 1 2: Address gripper 2	<i>bClosed</i> = <i>TRUE</i> , if gripper is open = <i>FALSE</i> , if gripper is closed	Outputs <i>TRUE</i> if the gripper is closed.
		<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	
ZISONTEACHPOS1 ZISONTEACHPOS2	1: Address gripper 1 2: Address gripper 2	<i>bIsOnTeachPos</i> = <i>TRUE</i> , if gripper is set to TeachPosition = <i>FALSE</i> , if gripper is not set to TeachPosition	Outputs <i>TRUE</i> if the gripper is set to <i>TeachPosition</i> .
		<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	
ZISONUNDEFPOS1 ZISONUNDEFPOS2	1: Address gripper 1 2: Address gripper 2	<i>bUndefPos</i> = <i>TRUE</i> , if gripper is set to Undefined-Position = <i>FALSE</i> , if gripper is not set to UndefinedPosition	Outputs <i>TRUE</i> if the gripper is set to <i>OnUndefinedPos</i> .
		<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	
ZISERROR1 ZISERROR2	1: Address gripper 1 2: Address gripper 2	<i>bError</i> = <i>TRUE</i> , if gripper is in error state = <i>FALSE</i> , if gripper is not in error state	Outputs <i>TRUE</i> if the gripper is in an error state.
		<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	
ZISMOTORON1 ZISMOTORON2	1: Address gripper 1 2: Address gripper 2	<i>bMotorOn</i> = <i>TRUE</i> , if motor is on = <i>FALSE</i> , if motor is off	Outputs <i>TRUE</i> if the motor of the gripper is switched on.
		<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	
ZISHOMINGOK1 ZISHOMINGOK2	1: Address gripper 1 2: Address gripper 2	<i>bHomeOk</i> = <i>TRUE</i> , if homing is OK = <i>FALSE</i> , if homing is not OK	Outputs <i>TRUE</i> if the referencing of the gripper is OK.
		<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	

Generated robot job name	Parameter In	Parameter Out	Function
ZISHOMINGSUCCESS1 ZISHOMINGSUCCESS2	1: Address gripper 1 2: Address gripper 2	<i>bHomeSuccess</i> = <i>TRUE</i> , if ZHOMING command was successful = <i>FALSE</i> , if gripper is not in error state at ZHOMING command  <i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Outputs <i>TRUE</i> if the referencing of the gripper is successful.
ZERRORWARNINGON1 ZERRORWARNINGON2	1: Address gripper 1 2: Address gripper 2	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Enables Error/Warning for robot if gripper is present.
ZERRORWARNINGOFF1 ZERRORWARNINGOFF2	1: Address gripper 1 2: Address gripper 2	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Disables Error/Warning for robot if gripper present.
ZISPARTDETACHED1 ZISPARTDETACHED2	1: Address gripper 1 2: Address gripper 2	<i>bPartDetached</i> = <i>TRUE</i> , if part is detached = <i>FALSE</i> , if part is not detached  <i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	<i>B[n]</i> = 1, if gripper of gripper type <i>Vacuum</i> signals <i>Part detached</i> . <i>B[n]</i> = 0, if part is not detached.
ZISPARTPRESENT1 ZISPARTPRESENT2	1: Address gripper 1 2: Address gripper 2	<i>bPartPresent</i> = <i>TRUE</i> , if part is present = <i>FALSE</i> , if part is not present  <i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	<i>B[n]</i> = 1, if gripper of gripper type <i>Vacuum</i> signals <i>Part present</i> . <i>B[n]</i> = 0 if part is not present.
ZISREADY1 ZISREADY2	1: Address gripper 1 2: Address gripper 2	<i>bReady</i> = <i>TRUE</i> , if input is switched on = <i>FALSE</i> , if input is not switched on  <i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	<i>B[n]</i> = 1 if gripper of gripper type <i>Vacuum</i> signals <i>Ready</i> . <i>B[n]</i> = 0 if gripper is not ready.
ZMATCHSTARTCHANGE1 ZMATCHSTARTCHANGE2	-	<i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	Is output before the gripper is changed for <i>MATCH</i> .
ZISMATCHCHANGEDONE1 ZISMATCHCHANGEDONE2	-	<i>bMatchChangeDone</i> = <i>TRUE</i> , if match was changed = <i>FALSE</i> , if match was not changed  <i>bCmdFail</i> = <i>TRUE</i> , if command fails = <i>FALSE</i> , if command was successful	For <i>MATCH</i> <i>B[n]</i> = 1 if gripper is connected successfully. <i>B[n]</i> = 0, if gripper is not connected successfully.

## 16 Error diagnosis

### INFORMATION



- More information can be found in the installation and operating instructions of the gripper.
- Please contact Customer Service if you have any questions.

## 17 RoHS declaration

in terms of the EU Regulation 2011/65/EU

### Name and address of the manufacturer:

**Zimmer GmbH**



Im Salmenkopf

77866 Rheinau, Germany



+49 7844 9138 0



[info@zimmer-group.com](mailto:info@zimmer-group.com)



[www.zimmer-group.com](http://www.zimmer-group.com)

We hereby declare that the incomplete machine described below

**Product designation:** Smart Communication Module

**Type designation:** SCM

conforms to the requirements of the directive in its design and the version we put on the market.

Michael Hoch

Authorized representative for the  
compilation of relevant technical  
documents

Rheinau, Germany, 2020-02-28

(Place and date of issuance)

Martin Zimmer  
(Legally binding signature)  
Managing Partner

## 18 Declaration of Conformity

As defined by the EC Directive 2014/30/EU on electromagnetic compatibility

### Name and address of the manufacturer:

**Zimmer GmbH**



Im Salmenkopf

77866 Rheinau, Germany



+49 7844 9138 0



[info@zimmer-group.com](mailto:info@zimmer-group.com)



[www.zimmer-group.com](http://www.zimmer-group.com)

We hereby declare that the product described below

**Product designation:** Smart Communication Module

**Type designation:** SCM

conforms to the requirements of the Electromagnetic Compatibility Directive 2014/30/EU in its design and the version we put on the market.

The following harmonized standards have been used:

DIN EN ISO 12100	Safety of machinery - General principles for design - Risk assessment and risk reduction
DIN EN 61000-6-3	EMC Generic standard, Emission standard for residential, commercial and light-industrial
DIN EN 61000-6-2	EMC Generic standard, Emission standard for industrial environments
DIN EN 61000-6-4	EMC Generic standard, Immunity for industrial environments

A full list of applied standards can be obtained from the manufacturer.

Kurt Ross

Authorized representative for the compilation of relevant technical documents

Rheinau, Germany, 2020-02-28

(Place and date of issuance)

Martin Zimmer  
(Legally binding signature)  
Managing Partner

## 19 Declaration of Conformity

In terms of the EU Directive 2014/35/EU (Low voltage directive)

### Name and address of the manufacturer:

**Zimmer GmbH**



Im Salmenkopf

77866 Rheinau, Germany



+49 7844 9138 0



[info@zimmer-group.com](mailto:info@zimmer-group.com)



[www.zimmer-group.com](http://www.zimmer-group.com)

We hereby declare that the product described below

**Product designation:** Smart Communication Module

**Type designation:** SCM

conforms to the requirements of the 2014/35/EC directive in its design and the version we put on the market.

The following harmonized standards have been used:

DIN EN ISO 12100	Safety of machinery - General principles for design - Risk assessment and risk reduction
DIN EN 60204-1	Safety of machinery – Electrical equipment of machines - Part 1: General requirements

A full list of applied standards can be obtained from the manufacturer.

Kurt Ross

Authorized representative for the  
compilation of relevant technical  
documents

Rheinau, Germany, 2020-02-28

(Place and date of issuance)

Martin Zimmer  
(Legally binding signature)  
Managing Partner